




INSTALLATION GUIDE
AND USER MANUAL
L3 SERIES LIMITLESS LITHIUM™

L3 HV-60kWh | L3 HV-40kWh

Effective Date: August 20, 2026





READ THE INSTRUCTIONS COMPLETELY BEFORE OPERATING THE EQUIPMENT

Information included in this Installation Guide is valid as of the Effective Date and is qualified, in its entirety, by the Disclaimer referred to below and by the terms of any applicable Limited Warranty. Sol-Ark reserves the right to make product modifications at any time without advance notice, which may affect information included in this Installation Guide or otherwise make this information inapplicable and out-of-date.

For the latest Sol-Ark product and installation documents, visit: sol-ark.com

For errors, omissions, or suggestions, contact support@sol-ark.com

For complete product specifications and information on relevant product listings and certifications, see the Product Datasheet at: sol-ark.com



Disclaimer

UNLESS SPECIFICALLY AGREED TO IN WRITING BY SOL-ARK IN A VALIDLY EXECUTED AND DELIVERED CONTRACT:

Sol-Ark assumes no responsibility or liability for any damages, property loss, personal injury, or any adverse consequences resulting from improper use or installation of the product or the failure to adhere to the guidelines provided in this Installation Guide. Users are expressly advised to follow the instructions and guidelines outlined in the documentation accompanying the product. Sol-Ark is not liable for any damages or losses incurred as a result of, or related to, any failure to comply with, or deviations from, recommended usage, installation, or maintenance procedures. By using the product, users acknowledge their understanding of these disclaimers and agree to use the product at their own risk. Sol-Ark reserves the right to update or modify product information, specifications, and guidelines without prior notice.

This Installation Guide is provided “as is,” without charge, and is intended solely for general informational purposes without any right or presumption of reliance. Your sole and exclusive remedy for any defects, or other issues associated with, or related to, any Sol-Ark product is limited and restricted solely to the Limited Warranty provided by Sol-Ark and included in any documentation provided by Sol-Ark or otherwise made available by Sol-Ark, whether through its website or otherwise. Failure to use the most recent, commercially available version of Sol-Ark software may void your warranty and may cause the performance or compatibility of your Sol-Ark product to be adversely affected. You are urged, at all times, to use the most recently available Sol-Ark software for any Sol-Ark product, including all updates, upgrades, and other modifications of that software made commercially available by Sol-Ark.

This Installation Guide is not intended to, and does not, supersede any instructions or directions that you may have received from the manufacturer of any other products that you may use in combination with a Sol-Ark. Sol-Ark makes no representation regarding energy system designs within which Sol-Ark products may be used, the use or integration of third-party hardware or software with Sol-Ark products, or necessary compliance with local rules or regulations. Changes to non-Sol-Ark manufactured products, including to software or hardware components of those third-party products, may have a material effect on the performance of Sol-Ark products and could void applicable warranties or otherwise harm the performance of Sol-Ark products. To the fullest extent permitted by applicable law, Sol-Ark hereby expressly and unconditionally disclaims liability for any and all indirect, incidental, exemplary, punitive, or consequential damages.

If you are uncertain about implementing or using any of the information contained in, or made available by, this Installation Guide, you are urged not to continue with this Installation Guide and immediately to contact Sol-Ark Technical Support. This Installation Guide does not modify, extend or change the terms of any Limited Warranty that may be applicable to your Sol-Ark products, and you should carefully consult those Limited Warranty terms to ensure that you may not be voiding or violating those Limited Warranty terms if you undertake any of the actions referred to in this Installation Guide.

Sol-Ark retains the right to final interpretation of this document and all related materials pertaining to this product. This document is subject to modifications, updates, revisions, or termination without prior notice. For the latest product information, visit Sol-Ark’s official website. www.sol-ark.com.

Any action related to the information included in this Installation Guide shall be governed by the internal laws of the State of Texas, United States of America, without giving effect to any conflicts of laws principles. Any action, suit, or other legal proceeding that is commenced to resolve any matter related to this Guide shall be commenced solely and exclusively in a state court sitting in Collin County, Texas (or, if appropriate, a federal court located within Collin County in the Eastern District of Texas), and you hereby consent to the personal jurisdiction of those courts.

This manual applies to only the **L3 Series Limitless Lithium™ Indoor Battery Energy Storage System**.

For Technical Support, contact:

(USA) +1 (972) 575-8875 ext. (2)

support@sol-ark.com

Contents

1. L3 Series at a Glance.....	1
1.1 What's in the box.....	1
1.2 L3 HV Components	2
1.3 Specifications.....	3
1.4 L3 HV Fastener Torque Table	4
1.5 L3 HV Datasheet.....	5
2. Installation	6
System Description	6
2.1 Parts List.....	7
2.2 Assembly	8
2.3 Equipment Clearance Guidelines	12
2.4 Seismic Installation Guidelines	13
2.5 Battery Overview.....	14
2.6 Wiring	15
2.7 Battery Communications	18
2.8 Powering-up the Sol-Ark L3 System.....	19
2.9 Power Cycle Sequence	20
3. User Interface	21
3.1 HMI Screens.....	21
3.2 System Setup.....	22
4. Operation and Maintenance	23
4.1 Maintaining the L3 System	23
4.2 Fire Suppression System	23
4.3 Recharging Over-Discharged Batteries	24
4.4 HMI Firmware Update Process	25
4.5 BCU Firmware Update Process	26
4.6 Long-Term Battery Storage.....	26
4.7 Wiring Diagrams	27
5. Error Codes	29
5.1 System Faults.....	29
5.2 Common Causes.....	30

Important Safety Instructions

This manual provides crucial information for the installation and operation of the L3 Series Limitless Lithium™ Battery Energy Storage System. Qualified and authorized personnel are required to conduct the installation and maintenance procedures adhering to all safety standards and system requirements outlined in this document.


This manual is applicable to countries that comply with the certification requirements. Standards and legal requirements of other countries might differ from the specifications outlined in this manual.

Symbols in this Document

-  **WARNING:** This symbol indicates information that, if ignored, could cause serious injury, equipment damage, or death.
-  **CAUTION:** This symbol indicates information that, if ignored, could result in minor injury or equipment damage.
-  **NOTE:** This symbol indicates relevant information that is not related to hazardous situations.

Symbols on the Equipment

-  **CAUTION:** Indicates risk of injury or equipment damage.
-  **RISK OF ELECTRIC SHOCK:** Indicates components that present risk of electric shock.
-  **DO NOT INCINERATE:** Do not dispose of product by incineration.
-  **RISK OF EXPLOSION:** Physical damage, fire, or over charging may cause Li-ion batteries to ignite and/or explode.
-  **RECYCLABLE:** Product is recyclable. Proper disposal is required.
-  **REFER TO INSTRUCTIONS:** Read operating and installation instructions before proceeding.
-  **cSGSUS:** SGS marking indicates NRTL product testing and certification for compliance with standards for North America and Canada.
-  **DO NOT THROW AWAY:** Proper disposal of inverters and/or batteries is required.



NFPA 704: The NFPA 704 diamond, often called the "fire diamond," is a system from the National Fire Protection Association (NFPA) to quickly communicate the hazards associated with a material.

It provides crucial information to emergency responders, such as firefighters, about the potential risks involved, enabling them to make informed decisions during emergencies.

Colors indicate the type of warning:

Blue Health

Red Flammability

Yellow Reactivity

White Space for additional Information

Numbers Indicates the severity from **0**—no special hazard—to **4**—severe hazard.

Notices

ATTENTION: Read all instructions and cautionary markings in this document and on the equipment before installing the L3 HV. Failure to do so may result in equipment damage, electric shock, serious injury, or loss of life. Failing to follow any of these instructions may also void the warranty.

All installations must conform to the laws, regulations, codes, and standards applicable in the jurisdiction of installation. Before starting an installation, consult a local building or electrical inspector for current requirements. Local codes may vary but are adopted and enforced to promote safe electrical installations. A permit may be needed to do electrical work, and some codes may require an inspection of the electrical work.

When installed in the US electrical installations are required to follow the National Electrical Code (ANSI/NFPA 70) adopted by their local AHJ (Authority Having Jurisdiction) including any local amendments.

General

WARNING: Risk of electric shock. Risk of fire. Only qualified electrical personnel should install, troubleshoot, service, or replace the equipment.

WARNING: Risk of electric shock. Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices during installation and service. Turn off all power supplying this equipment before working on or inside equipment. Always use a properly rated voltage sensing device to confirm power is off. Replace all devices, covers, and doors before turning on power to the equipment.

WARNING: Inspect the equipment for damage before installing. Do not install the equipment if it has been damaged in any way.

WARNING: Do not insert foreign objects into any part of the equipment.

WARNING: Do not expose the equipment or any of its components to direct flame.

WARNING: Do not attempt to open, disassemble, repair, tamper with, or modify the equipment other than what is permitted in this manual. The equipment contains no user-serviceable parts. Contact the installer who installed the equipment for any repairs.

WARNING: Do not connect life-support systems, other medical equipment, or any other use where product failure could lead to injury to persons or loss of life.

CAUTION: Do not use solvents to clean the equipment or expose the equipment to flammable or harsh chemicals or

vapors. Do not allow petroleum-based paints, solvents, or sprays to contact nonmetallic parts of the equipment.

CAUTION: Do not use parts or accessories other than those specified for use with the equipment.

Installation and Use

WARNING: Risk of electric shock. Risk of fire. Only use electrical system components approved for dry locations.

WARNING: Risk of electric shock. Risk of fire. Ensure that all wiring is correct and that none of the wires are pinched or damaged.

WARNING: Risk of electric shock. Risk of fire. Before making any connections, verify that the DC disconnect(s) are in the off position. Double-check all wiring before applying power.

WARNING: Risk of electric shock. Improper servicing of the equipment or its components may result in a risk of shock or fire. To reduce these risks, disconnect all wiring before attempting any maintenance or cleaning.

WARNING: Risk of electric shock. Always de-energize the equipment before servicing.

WARNING: Risk of electric shock. Do not use equipment in a manner not specified by the manufacturer. Doing so may cause injury or loss of life, or damage to equipment.

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Environmental Conditions

WARNING: This equipment is intended for operation in an environment having a minimum temperature of 4 °C (40 °F) and a maximum temperature of 43 °C (110 °F).

WARNING: Install the equipment in a location that prevents damage from flooding. Ensure that no water sources are above or near the equipment, including downspouts, sprinklers, or faucets.



Transportation and Handling

WARNING: To protect the equipment and its components from damage when transporting, handle with care. To help prevent damage, leave all equipment in its shipping packaging until it is ready to be installed.

WARNING: Risk of physical injury or death. The battery rack is not designed for transportation with modules installed. Do not attempt to lift a fully installed rack using any lifting device.

WARNING: Risk of physical injury or death. Vehicles used to transport lithium-ion batteries must comply with all DOT transportation regulations surrounding Class 9 hazardous freight.

WARNING: Risk of physical injury or death. Use caution when using lifting equipment to move battery modules and components.

WARNING: Risk of physical injury or death. Stacks of boxed battery modules should not exceed 8 units.

WARNING: Risk of physical injury or death. Each battery module weighs 44 kg (97 lbs). Use appropriate transport and lifting equipment for safe handling and transport.

WARNING: Risk of physical injury or death.

Requirements for Installation Personnel

All work MUST comply with local codes, regulations, and industry standards. The installation of the L3 system can only be completed by qualified persons with appropriate qualifications as determined by the local AHJ.

Product Disposal



You must not attempt disposal via normal waste collection or abandon the battery at a public facility.



Due to its considerable size, the L3 HV series battery storage system requires special handling to be recycled properly.

Li-ion




Proper recycling is crucial for lithium storage batteries. It keeps hazardous waste out of landfills and allows reusable materials like lithium and other metals to be recovered and repurposed. As the owner of the system, you are responsible for ensuring proper end-of-life recycling takes place through a certified lithium battery recycling program.

1. L3 Series at a Glance

1.1 What's in the box


The box should include all items shown in the components list below. If there are damaged or missing parts, immediately call Sol-Ark Technical Support at +1 (972) 575-8875 ext. 2.



Component	Description	Quantity	
		L3 HV-40kWh	L3 HV-60kWh
A	Battery Rack and Components (unassembled)	See "2.1 Parts List" on page 7	
B	L3 HV BCU 750 V Battery Control Unit (BCU)	1	
C	L3 HV 5.1 kWh Battery Module	8	12
D	Module Rack Mount Screws (M4 x 20)	90	100
E	4 AWG PushLok – Module to BCU Negative Cable	1	
F	4 AWG PushLok– Module Series Jumper	8	12
G	Battery module communication cable	8	12
H	Inverter communication cable	1	
I	120Ω RJ45 terminating resistor	1	
J	External 12 V power supply cord	1	
K	Battery rack grounding wire	1	
L	Battery Rack Screws Hex Key (4 mm)	1	
M	4 AWG PushLok – BCU to Inverter Cable (pos/neg)	2	

1.2 L3 HV Components

The L3 HV battery energy storage system includes the following components:





Component	Name	Component	Name
A	Battery Rack	I	Inverter (+, -) Connections
B	Battery Control Unit (BCU)	J	BCU to Module Internal Communication port
C	Battery modules	K	BCU USB Upgrade Interface
D	BCU Battery (+, -) Connections	L	BCU Communication Ports
E	HMI Touchscreen	M	External 12 V _{DC} Power Supply Input
F	BCU Start Button	N	200 A Dual Pole, BCU DC Disconnect Switch
G	High Voltage Indicator	O	Battery Module (+, -) Connections
H	Alarm Indicator	P	Module-to-Module Internal Communications Ports

1.3 Specifications




L3 HV-60kWh Dimensions



NOTICE: The size and dimensions of the following drawing of the L3 energy storage systems correspond to the L3 HV-60kWh model.





ISOMETRIC VIEW
REFERENCE ONLY






L3 HV-40kWh Dimensions



NOTICE: The size and dimensions of the following drawing of the L3 energy storage systems correspond to the L3 HV-40kWh model.



ISOMETRIC VIEW
REFERENCE ONLY



1.4 L3 HV Fastener Torque Table



Do not use impact drivers to tighten any fasteners on the L3 battery rack, BCU, or battery modules.

Connection	Torque [in-lb]	Torque [Nm]
BMU/Rack Grounding Screw	40 in-lb	4.5 Nm
BMU Mounting Screws	10.6 in-lb	1.2 Nm
Battery Module Mounting Screws	10.6 in-lb	1.2 Nm

1.5 L3 HV Datasheet

208V Options

Battery Energy Storage System

Battery Model Name:
ESS Model Name:
Sol-Ark Product SKU:

Outdoor

L3 HVR-60
L3 HVR-60KWH-30K
L3-HVR-60KWH

Indoor

L3 HV-40
L3 HV-40KWH-30K
L3-HV-40KWH

System Data		
Compatible Inverter Model	Sol-Ark 30K-3P-208V	
Cell Chemistry	Lithium Iron Phosphate	
Nameplate Energy Capacity (DC)	61.44 kWh	40.96 kWh
Usable Energy Capacity (DC) ¹	55.30 kWh	36.86 kWh
Built-In DC Disconnect Rating	200A	
Internal Fuse Rating	160A	
Max. # Battery Units Per Inverter	6	16
Max. # Inverters in Parallel	6	10
Recommend Depth of Discharge	90%	
Roundtrip Efficiency Charge/Discharge (DC)	94% (25C, 0.5C)	
System Nominal Voltage (DC)	307V	410V
System Operating Voltage (DC)	294V – 336V	392V – 448V
Battery Pack Internal Configuration	6s6p	8s1p
Charge/Discharge Current (DC) ²		
• Recommend	100A	50A
• Max. Continuous	100A	
• Peak Discharge (60 sec @ 25°C)	125A	
Battery Max. Continuous Charge/Discharge Power (DC)	61.44kW	40.96kW
ESS Max. Continuous Charge/Discharge Power (AC)	30kW	
Fault Current Contribution per Battery	4,200A / 1.47ms	
Mechanical Specifications		
Product Dimensions (WxDxH)	76x107x226 cm (30x42x89 in)	58x58x163 cm (23x23x64 in)
Net Weight	628 kg (1,384 lbs)	434 kg (957 lbs)
Mounting Type	Outdoor Enclosure	Freestanding Rack Mount
Material and Finish	Steel – Corrosion Resistant Powder Coat	Steel – Powder Coated
Operating Temperature ³ and Humidity	-20°C – 50°C (-4°F – 122°F) – 5%–85% RH	4°C – 43°C (40°F – 110°F) – 5%–85% RH
Operating Altitude ⁴	3000m (9,843 ft)	
Storage Conditions ⁵	-4°F – 95°F – Up to 85% RH (non-condensing) and State of Charge (SOC) 30%	
Ingress Rating	IP55 (NEMA 3R)	IP20 (NEMA 1)
Noise Level @ 1m	75 dBA at 30°C (86°F)	< 40 dBA at 30°C (86°F)
Seismic Mounting	Up to Category F	
Communication Ports	CAN2.0/RS485	
Battery Module Specifications		
Battery Module Nominal Energy Capacity	5.12kWh	
Battery Module Nominal Voltage and Capacity	51.2V / 100Ah	
Terminal Type	Amphenol SurLok – Push Lock Connector	
Warranty and Certification		
Performance Warranty ⁶	10 years or 196MWh Throughput	10 years or 130MWh Throughput
Product Warranty	10 Years	
Certifications	UL1973, UL9540, UL9540a, UN38.3, FCC, Prop 65	

1. DC usable energy, test conditions: 90% DOD, 0.3C charge and discharge at 25°C. System usable energy may vary due to system configuration parameters.

2. Output current is affected by battery temperature and SOC.

3. Temperature is based on the average cell temperature as measured by the BMS. Charging is disabled below 0°C (32°F). Derating occurs above 45°C (113°F). See Sol-Ark Technical Sales for outdoor sites.

4. Battery will operate at a maximum 1C charge/discharge up to 2000m, above 2000m maximum output is derated to 0.8C, contact Sol-Ark for details.

5. Storage temperature of the battery with no charge or discharge

6. EOL (End of Life) 70% retained capacity. See L3 Series warranty document for details.

Sol-Ark has a policy of continuous improvement and reserves the right to modify its specifications at any time and without prior notice. Please visit sol-ark.com for the latest information.


2. Installation

System Description

The L3 Series Limitless Lithium™ is a high-voltage lithium-ion battery designed for expandable energy storage and reliable backup power. The modular configuration of the L3 allows for expansion through the addition of battery racks. The capacity of the L3 system can be expanded up to 655 kWh and 983 kWh, for the L3 HV-40kWh and L3 HV-60kWh models, respectively.

The table shows the L3 HV models along with their respective capacities, module count, and additional parts:


Model	Modules	Total Energy Capacity	Parts
L3 HV-40kWh	8	40.96 kWh	8 x L3 HV-5.1kWh + L3 HV BCU-750 V
L3 HV-60kWh	12	61.44 kWh	12 x L3 HV-5.1kWh + L3 HV BCU-750 V



2.1 Parts List



NOTICE: The list below outlines the parts and assembly steps specific to the L3 HV-60 kWh model. This model is used as a reference for system assembly and installation. While the quantity of parts may differ for the L3 HV-40 kWh, the assembly steps are comparable, if not identical.




Component	Description	Quantity	
A	Pre-assembled left rack	1	
B	Pre-assembled right rack	1	
C	Top crossbeam	2	
D	Bottom crossbeam	2	
E	Left diagonal brace	1	
F	Right diagonal brace	1	
G	Mounting Feet	4	
H	Rack-to-Wall Angle Bracket (not for seismic installations)	3	
I	Battery Control Unit (BCU)	1	
J	L3 HV Battery Module	12	
K	Positive Link - Amphenol Battery Cable	1	
L	Series Link - Amphenol Battery Cable	11	
M	Negative Link - Amphenol Battery Cable	1	
N	RJ45 BCU-to-Module Communication Cables (140 mm)	1	
O	RJ45 Module-to-Module Communication Cable (110 mm)	7	11
P	Battery Rack Screws (M4 x 20)	90	100

2.2 Assembly

Follow the steps below to assemble the battery rack and install the BCU, battery modules, and the L3 system wiring. Carefully follow each step and verify proper assembly.

Assemble the Battery Rack


1



Place the left rack (**A**) on the floor to facilitate assembly. Affix the two top crossbeams (**C**) in position and pre-tighten using four screws (**P**). Install the two bottom crossbeams (**D**) and pre-tighten using four screws (**P**).


Note: To easily identify the bottom of the rack, locate the two square base plates containing welded nuts.

2




Use eight additional screws (**P**) to fully secure the crossbeams to the top and the bottom of the rack. Pre-tighten all screws before moving to the next step.

3




Gently lay the right rack (**B**) onto the previously assembled top and bottom crossbeams, ensuring correct orientation. Align each hole and secure in place with eight screws (**P**).

4



Use eight additional screws (**P**) to fully secure the right rack to the rest of the assembly. Tighten all screws before moving to the next step.


5



Proceed to the rear of the assembly. Install the left brace (E) and right brace (F) in their respective holes using eight screws (P).


Note: Once installed, the brace flanges will point inward toward the rack.

6



Attach the four mounting feet (G) to the underside of the rack assembly. Secure the feet by screwing them into the welded nuts of the bottom square base plates.


7



Gently raise the rack into an upright position. If in a **non-seismic** area, fasten the three angle brackets (H) using the three included screws (P) and attach to the wall surface using a suitable fastener for the material.

Insert the BCU


8



Carefully slide the BCU (**I**) into the top slot of the rack and secure in place using four screws (**P**).


Insert the Battery Modules

9



Gradually insert the battery modules (**J**) one by one into the remaining slots. Ensure proper installation by securing each module with four screws (**P**).


10




Install the battery module cables (**K**), (**L**) and (**M**) and wire the battery modules appropriately. See "2.6 Wiring" on page 15 for instructions.

Connect the Battery Communication Cables

11



12



Connect the battery communication cables **(N)** and **(O)** from module to module as described in "2.6 Wiring" on page 15.



WARNING: HEAVY EQUIPMENT. Structural damage can occur to the building due to static overload of the floor. Consult a licensed professional structural engineer when installing batteries above ground level.

2.3 Equipment Clearance Guidelines

The minimum clearances shown below between neighboring systems and surrounding walls are derived from Sol-Ark's UL9540A testing for the L3 HV series. It's essential to maintain these minimum distances to ensure compliance with the L3 HV UL9540A test report. This is particularly important in areas where it's required to follow NFPA 855 or similar local fire codes, such as the IFC.

1. Sides/Rear


- Maintain at least **60 cm [23.6 in]** of clearance between the battery sides and any walls or other barriers.
- Maintain at least **10 cm [4 in]** of clearance between adjoining battery racks.
- The rear requires **60 cm [23.6 in]** of clearance between the battery and any walls, barriers, or another battery.

2. Front

- **60 cm [23.6 in]** clearance is required in front of the battery racks to be able to open the door or install battery modules.
- Clearance may need to be increased if two batteries have doors facing each other.

3. Ceiling Height

- Install battery racks with a minimum ceiling height of **244 cm [96 in]** measured from the floor. This allows sufficient operator height.
- Ceiling access is not required for this system.



NOTICE: The clearance dimensions listed above are the minimum requirements. Additional clearance may be required by local fire codes or the Authority Having Jurisdiction (AHJ).

2.4 Seismic Installation Guidelines

When installing the L3 system, it is important to follow all bracing requirements to ensure structural integrity during a seismic event. Specific installation methods will depend on the requirements of your local AHJ, but the following general guidelines apply:

- Do not fasten the battery directly to drywall or use expanding anchors. The Sol-Ark-supplied mounting brackets must be secured to wall studs or other structural building elements.
- If installing on a raised floor, consult a licensed structural engineer to ensure the raised floor is rated for the weight and forces of the battery system for your seismic zone.




NOTICE: For information on pre-engineered, stamped designs for use in Category E seismic areas and above, contact Sol-Ark at: support@sol-ark.com or +1 (972) 575-8875, ext. 2.

After completing the L3 assembly, the total weight of the battery energy storage system is **434 kg (957 lb)** or **628 kg (1,384 lb)** for the L3 HV-40kWh and L3 HV-60kWh models respectively. Make sure that the installation site has sufficient load-bearing capacity to support the weight of the number of batteries installed.

2.5 Battery Overview

BCU



No.	Name	Description
1	Touchscreen HMI	Touchscreen Display for Battery Diagnostics and Settings Configuration
2	START	BCU Power Button
3	HV Indicator	High Voltage Present Indicator (yellow)
4	ALARM indicator	System Fault Indicator (red)
5	PCS-	Negative (-) – PushLok Connector to Inverter Input
6	PCS+	Positive (+) – PushLok Connector to Inverter Input
7	Grounding Terminal	Ground Point Between the Battery Rack and Module
8	B-	Negative (-) – Module PushLok Connector
9	B+	Positive (+) – Module PushLok Connector
10	DC Disconnect	200 A Dual Pole DC disconnect for the battery output (P+/P-)
11	USB	USB2.0 port for data logging or firmware updates
12	BCOM	Inter-battery communication port for the first battery module [INPUT/OUTPUT]
13	HVBOU	Communication output port to next L3 HV BCU [OUTPUT]
14	HVBIN	Communication input port for previous L3 HV BCU [INPUT]
15	PCS	RJ45 port for BCU to Inverter closed-loop communication [OUTPUT]
16	PWR	Input for External 12 V Power (for over-discharge recovery) [INPUT]

Battery Module



No.	Name	Description
1	B-	Negative (-) Amphenol battery module connector
2	B+	Positive (+) Amphenol battery module connector
3	BCOM IN	Communication port for previous battery module
4	BCOM OUT	Communication port to next battery module

2.6 Wiring



WARNING: Before wiring the system, ensure the BCU DC disconnect switch is turned OFF, and the MSD is disconnected.



DANGER: RISK OF DAMAGE. Battery modules provide power via BCOM IN and BCOM OUT ports. **DO NOT** connect PCS communications to either of these ports.

High-Voltage DC Wiring


Verify a secure installation of the BCU and battery modules onto the rack by following steps 8 and 9 of the assembly instructions. See “2.2 Assembly” on page 8 for more comprehensive details on how to assemble the battery rack.

1. Install the 220 mm battery conductor from the positive Amphenol battery connector (**B+**) of the BCU to the positive Amphenol battery connector (**B+**) of the first battery module.
2. Install the 200 mm battery conductors from module to module. Ensure connection in series from the negative Amphenol battery connector (**B-**) of the first battery module to the positive Amphenol battery connector (**B+**) of the subsequent battery module.




Inter-Module Series Jumpers

3. Connect the remaining battery conductors in the same way.
4. Install a long battery conductor from the last battery module to the BCU. This is done by linking the negative Amphenol battery connector (**B-**) of the last module to the remaining unconnected negative Amphenol battery connector (**B-**) of the BCU.



Main Negative Jumper


5. Connect the grounding wire from the BCU to any available hole in the top crossbeam of the battery rack. Safely fasten it in position using M4 and M6 screws.
6. Connect a grounding wire from the marked holes in the bottom crossbeam of the battery to the site's grounding system.
7. To interconnect an inverter, use the included Amphenol connectors. Run the wires from the positive and negative Amphenol connector (**P+**) and (**P-**) to the inverter's battery input terminals, as shown here.



Battery-to-Inverter Wiring

Communications Wiring

1. After all battery modules are installed, locate the included 140 mm (5.5 in) BMU communication cable. Connect one end to the **BCOM** communication port of the BCU. Then connect the other end to the **BCOM IN** communication port of the first module.



Inter-Module Communication Jumpers

2. Locate 7 pieces (or 11 pieces) of the 110 mm (4.3 in) inter-battery communication cables that connect the battery modules together.
3. Connect one end to the **BCOM OUT** communication port of the first battery module. Connect the other end to the **BCOM IN** communication port of the subsequent battery module.
4. Connect all remaining 110 mm (4.3 in) communication cables for the rest of the battery modules.



Terminating Resistor



NOTICE: The **BCOM OUT** port of the last battery module should be terminated with the included 120Ω terminating resistor plug.

2.7 Battery Communications


The L3 Series Limitless Lithium™ energy storage system employs a CAN (Controller Area Network) communication system to communicate among battery modules and daisy-chained BCUs of paralleled L3 stacks, up to 16 units. For PCS (Power Control System) devices like Sol-Ark hybrid inverters, the battery can communicate via CAN.




NOTICE: Only the 30K-3P-208V and 60K-3P-480V inverters are supported by the L3 Limitless Lithium™ series. In addition, only CAN-based battery-to-inverter communication is supported.

Battery communications are essential for correct operation and optimal performance. The following figures and tables give a detailed overview of the pin configuration of the different L3 system communication ports.

BCU (FRONT)




BATT MODULE (FRONT)



Pin	BMU
--	BCOM
1	BCU_CANL
2	BCU_CANH
3	DO+
4	DO-
5	GND
6	GND
7	12 V
8	12 V

Battery Module	
BCOM IN	BCOM OUT
BMU_CANL	BMU_CANL
BMU_CANH	BMU_CANH
DI+	DO+
DI-	DO-
GND	GND
GND	GND
12 V	12 V
12 V	12 V

BCU (BACK)



Pin	HV OUT
1	BCU_CANL
2	BCU_CANH
3	DI+
4	DI-
5	--
6	--
7	--
8	--

HV IN
BCU_CANL
BCU_CANH
DI+
DI-
--
--
--
--

PCS
485 B-
485 A+
--
PCANH
PCANL
--
485 A+
485 B-

2.8 Powering-up the Sol-Ark L3 System



CAUTION: Follow proper safety measures including lockout/tagout (LOTO) and wearing any OSHA required PPE when powering up and testing the system.

Verify Battery Module Voltage



The nominal voltage of a 5.1 kWh battery module is 51.2 V. Any voltage within a range of 50 V to 56 V is considered normal.

1. Use a digital multimeter to verify proper DC voltage between the B+ and B- connectors of the first battery module.
2. Repeat the measurement across **ALL** battery modules to confirm consistent voltage levels.
3. **DO NOT** commission a pack with a module-to-module voltage delta (between the highest and lowest) of more than **0.2 V_{DC}**.
 - a. If you have a module delta above 0.15 V, contact Sol-Ark Technical Support at (972) 575-8875 ext. 2 for next steps.

Verify Battery Stack Voltage

1.  After you verify that all battery modules are within 0.15 V_{DC}, use a digital multimeter to measure and verify that you get the correct **pack level voltage** between the B+ connector of the first battery module and B- connector of the last battery module.


This voltage is calculated according to the following equation: $V_{\text{pack}} = N_{\text{series}} \times V_{\text{module}}$

- For L3 HV-60kWh with a Sol-Ark 60K-3P-480V configuration: this should be between 588-672 V_{DC}
 - For L3 HV-40kWh with a Sol-Ark 30K-3P-208V configuration: this should be between 392-448 V_{DC}
2. Re-attach the cables and make sure that all PushLok connectors are properly seated.


Turn On the L3 System

1. Twist the handle clockwise to the **ON** position. The DC disconnect switch will click and latch in place.

Note: The DC disconnect features a built-in locking tab that can be used to lock out the disconnect in the **OFF** position for service and maintenance.



2. **PRESS** the BMU **START** button to the **ON** position. The Sol-Ark boot-up screen appears.



3.  The **high voltage "HV"** indicator will light up.
4. Wait a few seconds, then tap the screen once to access the home screen.


2.9 Power Cycle Sequence

1. **PRESS** the **START** button to the OFF position. The LCD screen will turn off.
2. **TURN OFF** the DC disconnect switch.
3. Make sure the **HV** light indicator is **OFF**.
4. Wait about one minute to be sure the inverter is completely de-energized.
5. To turn on the system, follow the steps on page 19.

3. User Interface

3.1 HMI Screens


Home Screen



Login Screen



System Maintenance Screen




3.2 System Setup


Battery communication of the L3 Series Limitless Lithium™ system automatically sets up the system and identifies the number of battery modules detected on the CAN bus. Follow these steps to access the system maintenance and configuration screen. Here, you can confirm these values and access detailed descriptions of the faults.



1. Tap the center of the screen to access the home screen menu.



2. At the top-right of the screen, tap the  icon to see the **System Maintenance** menu. A security screen will request a passcode.



3. Enter the passcode **1 2 3** onto the screen, then tap the  button to go to the **System Setup** menu.



- The **BMU Number** at the bottom-left shows how many battery modules are in the L3 system. This number automatically displays when there is proper communication between the battery modules and the BCU.
- The **Protocol ID** defines the CAN Bus communication protocol utilized by the L3 system. ID 0 should be selected for Sol-Ark Inverters.
- You can tap on each **Fault** icon positioned on the right and left sides of the screen to find additional information about faults, including detailed descriptions and common causes.



NOTE: If a fault occurs, the Alarm indicator on the BMU will light up, and the fault will be highlighted in red on both the **Home** screen and **System Maintenance** screen. On the **System Maintenance** screen, tap on a fault for more information.

4. Operation and Maintenance

4.1 Maintaining the L3 System



CAUTION: Follow proper safety measures including lockout/tagout and wearing any OSHA required PPE when powering-up and testing the system.

For safe operation, it's essential to thoroughly inspect all components of the L3 system, including but not limited to system conductors, connectors, wiring between modules, BCU, and ground. The following annual maintenance tasks and inspections should be performed by a qualified professional.

- Make a basic visual inspection of the system. Verify the tightness of all electrical connections, including any torque values listed in "1.4 L3 HV Fastener Torque Table" on page 4.
- Keep the unit clean and free of any dust and debris.




NOTICE: To clean the battery rack, BCU, or modules, use a soft, damp cloth to wipe down any surfaces. No harsh solvents or cleaning products should be used. Make sure that the battery connections remain free from any moisture.

4.2 Fire Suppression System

The L3 HV series features an integrated aerosol-based fire suppression system at the battery module level. In the rare event of a thermal runaway, the aerosol canister would rapidly deploy, filling the battery module interior with non-toxic agent to suppress any potential fire before spreading. This unique, industry-leading safety capability from Sol-Ark ensures maximum protection for commercial and industrial users.

Module Level: Contained in each module is a 12-gram aerosol agent canister, dispensing in a proprietary system which activates automatically when heat inside the module reaches potentially unsafe levels due to thermal runaway or external fires ($185\text{ }^{\circ}\text{C} \pm 10\text{ }^{\circ}\text{C}$).



Module-level aerosol agent canister

4.3 Recharging Over-Discharged Batteries

The Battery Management Unit (BMU) is designed to receive power directly from the battery stack. If the battery is left without a charging source for an extended time, the BCU and standby power consumption by the BMU and other system devices could lead to an over-discharge of the batteries, reaching below the required input voltage for BMU operation.

If this happens, use one of the processes below to restore power to the BMU:

Step 1. Before the recharge process

1. Turn off the battery stack by pressing the BCU power button and turning BCU disconnect to the OFF position.
2. Confirm that the battery module has reached an over-discharge state by removing the power cable and measuring voltage across positive and negative terminals.
3. If the voltage across any battery module is $<49\text{ V}$, remove the batteries from the stack by disconnecting power cables.
4. On the L3 BCU screen, change the BMU number to match the total modules not removed from the stack.
5. Charge the rest of the battery modules to 100% SOC using the inverter in normal operation.

Step 2. Recharge batteries that are over-discharged

Choose one of the methods below to recharge batteries.

A. Using a 48 V charger to recharge batteries

1. Connect a 48 V charger to the B- and B+ inputs of the over-discharged battery module that you removed.
2. Make sure that polarity is correct from the charger to the inputs.
3. Confirm that the 48 V charger is capable of charging the module to 54 V_{DC} (this may require a 54 V charger).
4. Make sure that no more than 10 A of current is charging the battery module.
5. Charge the battery module to the recommended 54 V_{DC} from the charger, then confirm with a multimeter.

B. Using a 12 V charger to recharge batteries

1. Move the over-discharged battery module to the first slot below the L3 BCU and connect the Battery Module communication cable from BCOM to BCOM. Wire the module BCU negative cable and the module series jumper from the battery to the BCU.

2. Plug the 12 V_{DC} power supply into the DC 12 V port of the L3 BCU.

Note: A 120 V_{AC} to 12 V_{DC} power supply will usually be the most available.

3. A special firmware will be loaded on the BCU following the same steps in “4.5 BCU Firmware Update Process” on page 26. Contact Sol-Ark to receive the BIN file for this specific firmware.
4. Use the CAN tool which has the **UpperComputer** app to adjust the voltage/current of the charger. Match the same voltage to the rest of the modules that charged to 100% SOC in Step 1.5 above.
5. Repeat the process for each module that was overly discharged.
6. After all modules are recharged, change the firmware of the L3 BCU back to its original version.

Step 3. After the battery recharge process

1. Reconfigure the battery back into the HV stack.
2. On the BCU user interface, change the BMU number to its original value.


Note: Make sure the difference between the minimum and maximum cell voltage doesn't exceed 15 mV across the stack.

4.4 HMI Firmware Update Process




CAUTION: Before opening the battery module, please contact Sol-Ark Technical Support at support@sol-ark.com or +1 (972) 575-8875, ext. 2

1. ⚠ Make sure the DC disconnect is turned **OFF** before doing any maintenance.
2. ⚠ Unplug **ALL** four B+, B-, P+ and P- conductors from the BCU and wait at least **5 minutes** before opening the unit.
3. Remove the top metal cover of the BCU by unscrewing all thirteen M4 screws as shown below.




4. Locate the SD card slot.



4.5 BCU Firmware Update Process

1. The USB port of the BCU allows for upgrading firmware and logging battery data.
2. To update the firmware, first format a USB 2.0 drive as **FAT32**, no larger than **8GB** in size.
3. In the root directory of the USB drive, create a new folder called “**upgrade**” all lowercase.
4. Place the .bin file provided by Sol-Ark in the **upgrade** folder on the USB drive.
5. Turn on the battery following the procedure outlined in “2.8 Powering-up the Sol-Ark L3 System” on page 19.
6. Insert the USB drive once the battery has completely turned on.
7. Within 5 seconds of inserting the USB drive, the blue light around the **Start** button will blink during the update process.
8. After the light turns off, remove the USB drive to complete the upgrade. During the process, do not power off the battery using the **Start** button or **DC disconnect**.
9. After the blue light around the **Start** button lights up again, the update should be complete.
10. Verify the version number displayed on the inverter under the Lithium Battery Information screen or by using the BCU diagnostic software.



4.6 Long-Term Battery Storage


When storing the assembled battery system for periods longer than 1 week, follow these recommended steps.

- To maximize battery lifespan, maintain storage temperature between 13 °C – 30 °C (55 °F – 86 °F).
- Power on and cycle the battery at least once every 6 months to maintain the SOC within 30-50%.
- Minimize BCU self-discharge by disconnecting the negative Amphenol battery connector (**B-**) during this period. This interrupts the power supply to the BCU, preventing battery discharge.


4.7 Wiring Diagrams



CAUTION: These diagrams are examples of some common setups. They may not cover all variations required by local codes and should not be solely relied upon for permitting or warranty purposes. Consult relevant authorities and be sure that you're in full compliance before installation. Installers should exercise caution, seek professional advice when necessary, and follow established electrical standards and regulations during all installations.



MultiStack Battery Wiring



Two Battery System Connections

5. Error Codes

5.1 System Faults



NOTE: For more information, contact: support@sol-ark.com or +1 (972) 575-8875, ext. 2

Fault	Potential Fault Cause
OT (Over Temperature)	BCU Positive connector overtemperature
	BCU Negative connector overtemperature
	Pre-charge resistor overtemperature level-2 alarm
	Heating film overtemperature level-2 alarm
	Charge overtemperature level-2 alarm
	Discharge overtemperature level-2 alarm
UT (Under Temperature)	Charge under temperature level-2 alarm
	Discharge under temperature level-2 alarm
OC (Over Current)	Charge overcurrent level-2 alarm
	Discharge overcurrent level-2 alarm
DV (Differential Voltage)	Excessive differential voltage level-2 alarm
DT (Differential Temperature)	Excessive differential temperature level-2 alarm
OV (Over Voltage)	Total charge voltage too high
	Cell overvoltage level 2 alarm
UV (Under Voltage)	Charge voltage too low
	Total discharge voltage too low
	Cell undervoltage level-2 alarm
OF (Other Fault)	Abnormal number of BMUs
	BMU lost
	RTC clock fault
	Current module fault
	SCHG total voltage acquisition fault
	Abnormal RS-485 communication
	RS-485 communication failure
	Inverter CAN communication failure
	Repeated BCU Address fault
	Repeated BMU Address fault
	Abnormal power supply voltage
	Heating relay Welded
	SOC low
	SOC high
	Internal Fuse Blown
	Charge Relay Welded
	Discharge Relay Welded
	Master Positive Relay Welded
	Temperature Acquisition Failure
	Cell voltage acquisition fault
	Inter-battery communication failure
	Pre-charge failure
	Insulation level 2 alarm
	External total voltage acquisition fault
	Internal total voltage acquisition fault
	Current acquisition fault
	Limit protection
	EEPROM failure
ISO	Insulation level 2

5.2 Common Causes

Fault Type	Common Cause
Charge over-current alarm	More than 105A for 2s; more than 125 A for 5 s; or more than 140 A for 2s; If the battery is operating below 5 °C (41 °F) then: 52.5 A for 2 s; more than 62.5 A for 5s; or more than 70 A for 2s;
Charge over-current protection	
Discharge over-current alarm	
Discharge over-current protection	
Charge overtemperature alarm	Exceeding the parameter set value and set time (>45 °C , 2s)
Charge overtemperature protection	Exceeding the parameter set value and set time (>50 °C, 2s)
Discharge overtemperature alarm	Exceeding the parameter set value and set time (>50 °C , 2s)
Discharge overtemperature protection	Exceeding the parameter set value and set time (>55 °C , 2s)
Charge under temperature alarm	Exceeding the parameter set value and set time (<5 °C , 2s)
Charge under temperature protection	Exceeding the parameter set value and set time (<0 °C , 2s)
Discharge under temperature alarm	Exceeding the parameter set value and set time (<-10 °C , 2s)
Discharge under temperature protection	Exceeding the parameter set value and set time (<-20 °C, 2s)
Excessive differential voltage alarm	Exceeding the parameter set value and set time (>500 mV, 2s)
Excessive differential voltage protection	Exceeding the parameter set value and set time (>800 mV, 2s)
Excessive differential temperature alarm	Exceeding the parameter set value and set time (>10 °C, 2s)
Excessive differential temp. protection	Exceeding the parameter set value and set time (>15 °C, 2s)
Cell overvoltage alarm	To maintain consistency, cut off the charging immediately when you reach full charge calibration rated voltage of 3.6 V. When the voltage drops to 3.35 V, restart it with the turned-off red light indicator. All protective red light indicators are always on.
Cell overvoltage protection	
Cell undervoltage alarm	
Cell undervoltage protection	
Pre-charge resistor overtemperature alarm	Exceeding the parameter set value and set time (>55 °C, 2s)
Pre-charge resistor overtemperature protection	Exceeding the parameter set value and set time (>65 °C, 2s)
Insulation level 1	Exceeding the parameter set value and set time
Insulation level 2	Exceeding the parameter set value and set time
Heating film overtemperature alarm	Exceeding the parameter set value and set time (>75 °C, 2s)
Heating film overtemperature protection	Exceeding the parameter set value and set time (>80 °C, 2s)
BMS connector overtemperature alarm	Exceeding the parameter set value and set time
BMS connector overtemperature protection	Exceeding the parameter set value and set time
BMU connector overtemperature alarm	Exceeding the parameter set value and set time
BMU connector overtemperature protection	Exceeding the parameter set value and set time
Power loop overtemperature alarm	Exceeding the parameter set value and set time
Power loop overtemperature protection	Exceeding the parameter set value and set time
SOC too low	Exceeding the parameter set value and set time
Total voltage too high alarm	Exceeding the parameter set value and set time
Total voltage too high protection	Exceeding the parameter set value and set time
Total voltage too low alarm	Exceeding the parameter set value and set time
Total voltage too low protection	Exceeding the parameter set value and set time
Discharge relay adhesion	Relay feedback information state welded
Charge Relay Welded	Relay feedback information state welded
Heating Relay Welded	High voltage is detected after disconnecting the heating relay
Limit protection	Exceeding the parameter set value and set time

Fault Type	Common Cause
Abnormal power supply voltage	Exceeding the parameter set value and set time
Master positive Relay Welded	Relay feedback information state adhesion
Fuse Blown	No high voltage is detected after the relay is closed
Repeated BMU address fault	BMU with the same number
INTER-CAN BUS communication failure	Loss of communication between BCU
PCS-CAN BUS communication failure	The heartbeat message of the inverter has not been received for a long time
RS-485 communication failure	Inverter RS-485 access is not received for a long time
Abnormal RS-485 communication	Contact Sol-Ark Technical Support.
External total voltage acquisition fault	Contact Sol-Ark Technical Support.
Internal total voltage acquisition fault	The difference between the acquired internal total voltage and the accumulated internal total voltage exceeding the set value
SCHG total voltage acquisition fault	Contact Sol-Ark Technical Support.
Cell voltage acquisition fault	The cell voltage acquired is 0
Temperature acquisition failure	The temperature acquired is -40 °C
Current acquisition fault	Contact Sol-Ark Technical Support.
Current module fault	Abnormal Hall Effect current sensor voltage
EEPROM storage failure	EEPROM write failure during self-test
RTC clock fault	The external RTC failed to enable the charging function
Pre-charge failure	Battery pre-charge timeout
Charging voltage too low	The minimum cell voltage is lower than the set value
BMU lost	BMU message not received for a long time
Abnormal number of BMU addresses	The number of BMU addresses is different than the number of set parameters

